



Acer Aspire 4743-6481 Battery Replacement

This guide provides detailed instructions on how to remove and replace the battery of the Acer Aspire 4743-6481.

Written By: Filippo Santoro



INTRODUCTION

If your device's battery depletes quickly or doesn't last at all while unplugged, you should use this guide to replace it with a new one.



TOOLS:

- [Tweezers](#) (1)
-

Step 1 — Battery



- Turn over the laptop to view the underside.

Step 2



- Use tweezers (or a similar tool) to slide the orange push pin. To release the battery, push it to the left.

Step 3



- You can lift the battery up and out now.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 03:50:58 AM.